# Quality used Equipment for sale

# **2011 TAKEUCHI TB235C**

**Description:** MINI EXCAVATOR 7400-9199#

Meter: 2,871

**Serial #:** 123501787

**Equipment #:** 1215844

**Price:** \$26,183 (USD)

United Rentals (Store D64) 3595 FM 1960 W HUMBLE, TX 77338-3363

Mon-Fri: 7:00AM-5:00PM Sat: CLOSED Sun: CLOSED

Sales Contact: KIMI RANKIN (281) 821-2554 krankin@ur.com









2011 TAKEUCHI TB235C PRICE: \$26,183 (USD) HUMBLE, TX (281) 821-2554







# **United Guard™**

# SAFEGUARD YOUR USED EQUIPMENT WITH PROTECTION YOU CAN TRUST

With United Guard, you'll benefit from reduced downtime, higher resale value, and fewer service interruptions.

## With United Guard You'll Receive:

- Free equipment inspections
- Warranted repairs on listed components
  - No co-pays on any covered repairs
- Service at any of our more than 880 locations in North America

For program details contact your local branch or call 800.UR.RENTS.

## UNITED GUARD ELIGIBILITY REQUIREMENTS

- Equipment must have a sale price of at least \$2,500 and must be less than 9 years old at the time of sale
- Equipment must be geographically located within the United Rentals range of service
- United Guard is only for the benefit of the original purchaser and is not transferable
- Entities that intend to sell or rent the equipment purchased are not eligible for United Guard
- United Guard must be purchased within 72 hours of equipment purchase
- United Rentals, Inc. (and its subsidiaries) makes no warranties to those defined as consumers in the Magnuson-Moss Warranty-Federal Trade Commission Improvement Act
- Powered licensed vehicles and trailers are not eligible



UnitedRentals.com 800.UR.RENTS

# **Parts Table**

Not every component is covered by this agreement. Coverage and exclusions are detailed below.

## UNITED GUARD COVERAGE INCLUDES

**ENGINE:** 

**Engine Block** 

Cylinder Liners

Piston

Piston Rings

Piston Pins

Cylinder Heads

Head Gasket

Crankshaft

Main Bearings

Con Rods

Con Rod Bearings

**Balance Assemblies** 

Camshaft

Push Rods

**Tappets** 

Valves

Springs

Guides

**Timing Gears** 

Lubrication Pump

**Drive Components** 

Casting Assembly

Thrust Bearings Internal Oil Seals

External Oil Seals (internal failure)

External Pump Drive Gear

#### TRANSMISSION/TRANSAXLE:

**Charging Pumps** 

Gear Train

Shafts

Thrust Washers

Needle Roller Bearings

Bearings

Gears

Internal Seals

Input and Output Seals (internal failure)

Clutch Packs Couplings

Oil Lubrication Pumps

Main Control Valves

Relief Valves

**Torque Converter** 

Gearshift Controller

Electronic Control (black-box)

Transmission Casing

PTO Drives

#### **DRIVE LINES:**

Main Shafts

Sliding Points

Flange/Yoke end of Drive Lines

Pivot Shaft

**Pivot Shaft Support Bearings** 

#### **DRIVE AXLES/FINAL DRIVES:**

Bearings

Shafts

**Thrust Washers** 

Seals

Input Seals (internal failure)

**Tension Springs** 

**Bull Gears** 

**Pinions** 

Ring Gears Crown Wheels

Internal Differential Gears and Locks

Differential Case

Yokes

Wheel Hubs

#### **ELECTRICAL:**

**Batteries** 

Wiring

Motors

Solenoids Solenoid Valves

Electric Instrument Panel

Switches

Relays

Sender Units

Hour Meters

Gauges

Sensors

Black-box

Microprocessor/ECU/ECM

Starter Motor

Alternator

Regulators

Controllers Generators

Coils

#### **COOLING SYSTEM:**

Hoses

Fan Belts

Blowers Fans

Fan Belt Tensioners

Water Pump

Internal Bearings and Seals

Fan Thermostat Thermostat

Oil Coolers

Radiators

Cab Heating Assembly

Intercoolers Aftercoolers

Heat Exchangers

Air Conditioners

**FUEL SYSTEMS:** 

Injectors

Fuel Injection Pump

Fuel Lift Pump

**Engine Priming Pump** 

Fuel Tanks

Carburetors

Propane regulators

Hoses and Fittings

#### **HYDRAULICS:**

Hoses

"O"-rings

External Seals

**Exposed Pipes** 

**Rubber Mountings** Hydraulic Tank Breathers

Hydraulic/Hydrostatic Motors

Hydraulic/Hydrostatic Pumps

Hydraulic Control Valves

Relief Valves

Accumulators

Shuttle Valve

Hydraulic Tank and Mounting

Hydraulic Cylinders (rams)

Electro/Hydraulic Valves Check Valves

#### MAIN FRAME/CHASSIS:

Chassis

Mainframe

Track Frames

Equalizer Bars/Pivot

Cylinder Mountings

Pins

Bearings

Bushes

Seals

Trunion, Trunion Housing and Trunion Brackets

Axle Mountings

Steering Cylinder Mountings Axle Trunion

Mast

Mast Rollers

Carriage

Carriage Rollers

Boom

Tele-boom

**Boom Mountings** 

**Boom Cylinder Mountings** 

### Stabilizer CASTINGS AND CASINGS, UNDERCARRIAGE.

IDLERS, TRACK ADJUSTERS, RUNNING GEAR:

Bearings

Shaft

**Thrust Washers** 

Seals Input Seals (internal failure)

Front Idlers

Idler Shafts

Track Adjuster Assembly

**Tension Springs** 

**Bull Gears** 

**Pinions** 

Crown Wheels Yokes

Steering and Brake Controls

Final Drive Shaft Sprockets/Segments (for breakage where applicable)

Compressor Air End Components Generator/Welder Electrical End Components

Water Pump - Pump End Components **ROPS & FOPS Structures** 

OTHER COMPONENTS:

# **EXCLUSIONS:**

The following wear items/parts are excluded:

Air Filter

Oil Filter

Fuses Tires and Tubes

Cosmetic Items

Non-functional Parts